


Installation and Operation Manual

Flex-Trunk™ Plus Extraction Arms



Throughout this manual, statements indicating precautions necessary to avoid equipment failure are referenced in a Note. Statements indicating potential hazards that could result in *personal injury* or *property damage* are referenced in a **Caution!** box.

This manual is the property of the owner. Leave with the unit when set-up and start-up are complete. Donaldson Company reserves the right to change design and specifications without prior notice.



Caution!

Application of Dust Control Equipment

- Combustible materials such as buffing lint, paper, wood, aluminum or steel dust, weld fume, or flammable solvents represent fire or explosion hazards. Use special care when selecting and operating all dust or fume collection equipment when combustible materials are present to protect workers and property from damage due to fire and/or explosion. Consult and comply with National and Local Codes relating to fire or explosion and all other appropriate codes when determining the location and operation of dust or fume collection equipment.
- When combustible materials are present, consult with an installer of fire extinguishing systems familiar with these types of fire hazards and local fire codes for recommendations and installation of fire extinguishing and explosion protection systems. Donaldson dust collection equipment is not equipped with fire extinguishing or explosion protection systems.
- DO NOT allow sparks, cigarettes or other burning objects to enter the hood or duct of any dust or fume control equipment as these may initiate a fire or explosion.
- For optimum collector performance, use only Donaldson replacement parts.

Warning – Improper operation of a dust control system may contribute to conditions in the work area or facility that could result in severe personal injury and product or property damage. Check that all collection equipment is properly selected and sized for the intended use.

| | | | |
|---|----|--|----|
| Description | 4 | Power Pack Assembly | 12 |
| Purpose and Intended Use | 4 | Electrical Connection | 12 |
| Operation | 4 | Optional Equipment | 16 |
| Inspection on Arrival | 4 | Preliminary Start-up Check | 16 |
| Installation Codes and Procedures | 5 | Service Information | 16 |
| Electrical Wiring | 5 | Parts Drawing 1, Extraction Arms | 18 |
| Standard Equipment | 6 | Parts Drawing 2, Power Pack Assembly, 6" | 22 |
| Wall-Mount | 6 | Parts Drawing 3, Control Box for 6" | 24 |
| Bench Mount | 7 | Parts Drawing 4, Extension Boom | 26 |
| Extension Boom | 8 | Limited Warranty | 28 |
| Extension Boom Adjustment | 10 | | |
| Maintenance | 10 | | |
| Arm Adjustment | 10 | | |
| Hood Adjustment | 10 | | |
| Initial Joint Adjustment | 10 | | |
| Upper Joint | 10 | | |
| Lower Joint | 10 | | |



This manual contains specific precautionary statements relative to worker safety. Read thoroughly and comply as directed. Discuss the use and application of this equipment with a Donaldson representative. Instruct all personnel on safe use and maintenance procedures.

Data Sheet

Model Number _____ Serial Number _____

Ship Date _____ Installation Date _____

Customer Name _____

 Address _____

 Filter Type _____

 Accessories _____

 Other _____

Description

The Flex-Trunk™ Plus extraction arm is designed to carry dust, fume, and mist away from the worker's breathing zone. The extraction arms are available in bench- or overhead-mount applications. The Flex-Trunk Plus has a unique external counterbalance that uses no friction discs. A spring, hidden inside the counterbalance assembly, is factory balanced and easily fine-tuned with the hex tool included.

Available in a wide range of sizes, the extraction arms are constructed with black-coated mild steel and include a plastic hood with handle.

Purpose and Intended Use

The source collection arms are designed to carry dust, fume, and mist away from the worker's breathing zone. Typical pollutants, up to 10-microns in size, include fume, vapor, metal dust, weed dust, and plastic dust. Typical airflow ranges and applications for each size are shown in the table below.

| Size | Typical airflow | Application |
|---------------|-----------------|--|
| 4-in diameter | 350 cfm | Soldering, TIG welding |
| 6-in diameter | 800 cfm | Moderate wire feed and stick welding |
| 7-in diameter | 1,000 cfm | Flux core wire and stick welding, plasma cutting |



Caution!

- Misuse or modification of this equipment may result in personal injury.
- Do not misuse or modify.

Operation

The operator positions the hood 12- to 18-inches above the work area. Contaminated air is drawn into the hood, through the Flex-Trunk Plus, and exhausts out of the work area.

Inspection on Arrival

1. Inspect unit on delivery.
2. Report any damage to the delivery carrier.
3. Request a written inspection report from the Claims Inspector to substantiate claim.
4. File claims with the delivery carrier.
5. Compare unit received with description of product ordered.
6. Report incomplete shipments to the delivery carrier and your Donaldson representative.
7. Remove crates and shipping straps. Remove loose components and accessory packages before lifting unit from truck.

Installation Codes and Procedures

1. Safe and efficient operation of the unit depends on proper installation.
2. Authorities with jurisdiction should be consulted before installing to verify local codes and installation procedures. In the absence of such codes, install unit according to the National Electric Code, NFPA No. 70-latest edition.
3. A qualified installation and service agent must complete installation and service of this equipment.

Electrical Wiring



Caution!

- Electrical installation must be performed by a qualified electrician and comply with all applicable national and local codes.
- Lock out electrical power sources before performing service or maintenance work.
- Do not install in classified hazardous atmospheres without an enclosure rated for the application.

1. All electrical wiring and connections, including electrical grounding, should be made in accordance with the National Electric Code, NFPA No. 70-latest edition.
2. Check local ordinances for additional requirements that apply.
3. The appropriate wiring schematic and electrical rating must be used. See unit's rating plate for required voltage.
4. If the unit is not furnished with a factory-mounted disconnect, an electric disconnect switch having adequate amp capacity shall be installed in accordance with Part IX, Article 430 of the National Electrical Code, NFPA No. 70-latest edition. Check unit's rating plate for voltage and amperage ratings.
5. Refer to the wiring diagram for the number of wires required for main power wiring and remote wiring.

Standard Equipment

Wall-Mount



Caution!

- Use appropriate lifting equipment and adopt all safety precautions needed for moving and handling the equipment.
- A forklift is recommended for unloading, assembly, and installation of the extraction arm.
- Location must be clear of all obstructions, such as utility lines or roof overhang.

1. Fasten the wall bracket to the wall, level with the floor, using suitable customer-supplied anchor bolts. See Bracket Installation.



Caution!


- Failure to mount the wall bracket properly can result in arm assembly collapse.
- Anchor bolts must be sized to support loads up to 500 lb.

2. Fasten the rotary-bearing assembly to the wall bracket using M8 x 40 screws and M8 hex nuts supplied.
3. Carefully lift the arm and attach to the rotary-bearing assembly using M8 x 16 hex-socket recessed pan-head screws and M8 hex nuts supplied.
4. Connect the hose to the rotary-bearing assembly using the clamp supplied. See Hose to Bracket and Rotary Bearing Assembly.
5. Ground the arm by connecting the points of contact with copper-strand wire with a suitable cross-sectional area. Attach to the equipment to ensure electrical continuity.




Caution!


- Failure to ground the arm properly can result in electrical shock.
- Install a proper ground.



Bracket Installation




Rotary Bearing to Wall Bracket Assembly



Hose to Bracket and Rotary Bearing Assembly

Bench Mount

1. Fasten the extraction arm to the collector using the screws provided. See Bench Mount Assembly.
2. Review the bolt pattern for 6-in OD Flex-Trunk Plus and for the 4- and 7-in OD Flex-Trunk Plus. Fasten the arm to the unit. On arms with a four-bolt bolt pattern, use the adapter ring supplied and fasten the arm to the adapter ring.
3. If arm is equipped with a light, switch, grill, and cable assembly push the cable through the electrical cover to the control box.




Bench Mount Assembly

Extension Boom

The modular extension boom increases the range of action of the extraction arms.


1. Install the wall bracket to the wall, level with the floor. Fasten using suitable customer-supplied bolts. See Extension Boom Wall Bracket.




Extension Boom Wall Bracket

2. Assemble the extension boom base and bottom using the hardware supplied. See Extension Boom Assembly.
3. Position the assembled extension boom in the wall bracket and fasten as shown.


4. Fasten one end of the tie rod to the wall bracket and the other end to the extension boom using the hardware supplied. Check that the extension boom is level to the floor. See Tie-Rod Connection.
5. Fasten the galvanized duct to the tie-rod with the clips provided. See Duct Installation.
6. Connect the 39-in rear hose to the galvanized duct.
7. Attach the wheel sleeve to the extension arm bottom using the supplied hardware as shown. See Wheel Sleeve Installation.
8. Complete the extension boom installation by connecting the 27-in front hose as shown in Duct Installation.
9. If the extraction arm is equipped with a light ground the arm by connecting the points of contact using copper-strand wire with a suitable cross-sectional area. Attach to the equipment to ensure electrical continuity.




Extension Boom Assembly



Tie-Rod Connection



Duct Installation




Wheel Sleeve Installation

Extension Boom Adjustment

To increase or decrease the pressure of the supporting pin on the base, calibrate the extension boom using the adjustment studs and a size 6 Allen wrench. See Extension Boom Adjustment.

Maintenance

1. Check tension bar bracket and supporting pin pressure once a month. Adjust as shown in Extension Boom Adjustment.
2. Check hose and duct conditions monthly.



Extension Boom Adjustment

Arm Adjustment

Hood Adjustment


Adjust the friction on the three hood swivel nuts as shown in Hood Adjustment. **Do not** over tighten.

Initial Joint Adjustment

Each extraction arm has two adjustment points. The upper joint is protected with a spring protection cover, and the lower joint is covered with a plastic plug.

Upper Joint

1. Position the extraction arm in the closed position as shown in Joint Adjustment.




Hood Adjustment

2. Shift the connecting hose between the two arm segments to access the spring protection cover. Remove the cover using a flat screwdriver.
3. Use the adjustment key or a deep-well 17 mm socket with extensions to adjust the tension. Clockwise adjustment increased the amount of force the operator must use to extend the arm, but decrease the effort required to retract the arm. Counterclockwise adjustment increases the amount of force the operator must use to retract the arm and decrease the effort required to extend the arm.

Lower Joint

4. Position the extraction arm in the open position as shown in Joint Adjustment.
5. Remove the plastic plug from the lower joint.
6. Use the adjustment key or a deep-well 17mm socket with extensions to adjust the tension. Clockwise adjustment increased the amount of force the operator must use to extend the arm, but decrease the effort required to retract the arm. Counterclockwise adjustment increases the amount of force the operator must use to retract the arm, but will decrease the effort required to extend the arm.



Joint Adjustment

Power Pack Assembly

1. Place the power pack adapter on the wall bracket.
2. Position the power pack adapter ring on the opposite side of the wall bracket.
3. Align the bolt patterns of the power pack adapter and the wall bracket to the adapter ring weld nuts and secure using four 5/16-18 x 1-in bolts.
4. Position the blower housing on the top of the power pack adapter using four 5/16-18 x 1-in bolts, lock washers, and hex nuts.
5. Apply sealant onto the blower housing's motor mount surface.
6. Attach the motor mount plate to the motor and fasten using four 3/8-16 x 3/4-in bolts and lock washers. Torque to 20 ft/lbs.
7. Position the blower wheel on the motor shaft
8. Position the blower wheel so there is 1/16-in clearance between the blower wheel and the blower inlet ring located inside the blower housing.
9. Insert the key into the blower wheel and motor-shaft key slot. Tighten the two setscrews to secure the blower wheel to the motor shaft.
10. Install the motor, blower wheel, and motor mount plate assembly on the blower housing by aligning the bolt patterns. Fasten using eight, 1/4-20 x 3/4-in screws.


Electrical Connection




Caution!

- Electrical installation must be performed by a qualified electrician and comply with all applicable national and local codes.
- Lock out electrical power sources before performing service or maintenance work.
- Do not install in classified hazardous atmospheres without an enclosure rated for the application.


1. A fused-disconnect with fuses and electrical connections of adequate capacity are customer supplied.
2. Mount the control box in a convenient location.
3. Install conduit and wire from the power source to the extraction arm.
4. Use the wiring diagram in this manual or inside the electrical control box to make the wiring connections to the blower motor and the light and switch cable.
5. In grounded systems, neutral to control box must be connected to L2 in the electrical control box. See Single Phase Wiring, Three-Phase Wiring, and Control Box Component Layout.



Single Phase Wiring Diagram



Three Phase Wiring Diagram



Control Box Assembly

Optional Equipment

Optional Light

The optional 12-Volt AC, 65-Watt halogen light is located in the extraction arm hood and controlled by a switch located in the hood handle. The switch can also control the blower circuit through a 12-Volt AC relay. The relay energizes the 120-Volt AC fan starter relay coil located in the electrical control box assembly.

Preliminary Start-Up Check

1. Check all electrical connections for tightness and contact.
2. Check for and remove all loose items in or near the inlet and outlet of the unit.
3. Check that all remote controls are wired into the control system, and all service switches are in the OFF position.
4. Check that all optional accessories are installed properly and secured.
5. Turn power ON at source.
6. Turn the fan motor ON then OFF to check for proper rotation by referencing the rotation arrow located on the motor's mounting plate.

Important!

Do not look into fan outlet to determine rotation.

7. Check that the exhaust plenum is free of tools or debris before checking blower/fan rotation.
8. Stand clear of exhaust to avoid personal injury.

To reverse rotation, single-phase power supply:
Follow manufacturer's instructions on the motor's nameplate.

To reverse rotation, three-phase power supply:
Turn electrical power OFF at source and switch any two leads on the output-side of the fan-motor starter.


Service Information

Monthly Maintenance Check

1. Check the arm tension.
2. Check the flexible duct condition.
3. Check the joint and friction pad for wear.
4. Check the bearing and pivot for wear.
5. Check the damper and damper handle for wear.

This Page Intentionally Left Blank

Replacement Parts



Parts Drawing 1, Extraction Arms

| Item | Part Number | Description | Model |
|--|-------------|-------------------------------------|-------|
| Bench Mount 4-in OD, 7-ft and 10-ft | | | |
| 1 | 8P P7537301 | Hood without Handle Aluminum | All |
| 2 | 8PP 7537304 | Flexible Hose, 4-in OD x 25.6-in | All |
| 3 | 8PP 7537302 | Flexible Hose 4-in OD x 15.75-in | All |
| 4 | 8PP 7537305 | Flexible Hose 4-in OD x 32.68-in | All |
| 5 | 8PP 7537303 | Rotary Bearing | All |
| 6 | 8PP 7537306 | Articulated Support 4-in OD x 7-ft | 7-ft |
| 6 | 8PP 7537307 | Articulated Support 4-in OD x 10-ft | 10-ft |
| 7 | 8PP 7537308 | Black Handle 4-in, 7-in | All |
| 8 | 8PP 7537325 | Damper Assembly 4-in | All |
| 9 | 6MM 7556601 | Collar, 4-in OD, Not Shown | All |

| Item | Part Number | Description | Model |
|---|-------------|--------------------------------------|-------|
| Bench Mount 6-in OD, 10-ft and 14-ft | | | |
| 1 | 8PP 7537309 | Hood without Handle, 6-in OD Plastic | All |
| 2 | 8PP 7537312 | Flexible Hose, 6-in OD x 25.6-in | All |
| 3 | 8PP 7537313 | Flexible Hose, 6-in OD x 15.75-in | All |
| 4 | 8PP 7537310 | Flexible Hose, 6-in OD x 32.68-in | All |
| 5 | 8PP 7537311 | Rotary Bearing, Bench Mount | All |
| 6 | 8PP 7537314 | Articulated Support, 6-in OD x 10-ft | 10-ft |
| 6 | 8PP 7537315 | Articulated Support, 6-in OD x 14-ft | 14-ft |
| 7 | 8PP 7537316 | Hood Handle | All |
| 8 | 8PP 7537326 | Damper Assembly, 6-in | All |
| 9 | 8PP 7537336 | Light and Switch Kit, Not Shown | All |
| 10 | 8PP 7537337 | Adapter Ring, Not Shown | All |
| 11 | 8PP 7537335 | Switch, Not Shown | All |
| 12 | 8PP 2738200 | Halogen Lamp, Not Shown | All |
| 13 | 8PP 7543701 | Grommet, Not Shown | All |


Overhead-Mount 6-in OD, 10-ft and 14-ft

| | | | |
|----|-------------|--|-------|
| 1 | 8PP 7537309 | Hood without Handle, 6-in OD Plastic | All |
| 2 | 8PP 7537312 | Flexible Hose, 6-in OD x 25.6-in | All |
| 3 | 8PP 7537313 | Flexible Hose, 6-in OD x 15.75-in | All |
| 4 | 8PP 7537310 | Flexible Hose, 6-in OD x 32.68-in | All |
| 5 | 8PP 7543801 | Bracket and Rotary Bearing, Overhead Mount | All |
| 6 | 8PP 7537314 | Articulated Support, 6-in OD x 10-ft | 10-ft |
| 6 | 8PP 7537315 | Articulated Support, 6-in OD x 14-ft | 14-ft |
| 7 | 8PP 7537316 | Hood Handle | All |
| 8 | 8PP 7537326 | Damper Assembly, 6-in | All |
| 9 | 2SG 7537336 | Light and Switch Kit, Not Shown | All |
| 9 | 3EA 7556701 | Assembly Grill without Light, Not Shown | All |
| 10 | 8PP 7537337 | Adapter Ring, Not Shown | All |
| 11 | 8PP 7537335 | Switch, Not Shown | All |
| 12 | 8PP 2738200 | Halogen Lamp, Not Shown | All |
| 13 | 6MM 4053701 | Wall Mount Bracket, Not Shown | All |

Parts Drawing 1, Continued


| Item | Parts Number | Description | Model |
|--|--------------|---------------------------------------|-------|
| Overhead-Mount 7-in OD, 10-ft and 14-ft | | | |
| 1 | 8PP 7537317 | Hood without Handle, 7-in OD Aluminum | All |
| 2 | 8PP 7537320 | Flexible Hose, 7-in OD x 17.7-in | All |
| 3 | 8PP 7537321 | Flexible Hose, 7-in OD x 25.6-in | All |
| 4 | 8PP 7537318 | Flexible Hose, 7-in OD x 32.68-in | All |
| 5 | 8PP 7543901 | Bracket and Rotary Bearing, 7-in OD | All |
| 6 | 8PP 7537322 | Articulated Support, 7-in OD x 10-ft | 10-ft |
| 6 | 8PP 7537323 | Articulated Support, 7-in OD x 14-ft | 14-ft |
| 7 | 8PP 7537308 | Black Handle, 4-in, 7-in | All |
| 8 | 8PP 7537327 | Damper Assembly, 7-in | All |
| 9 | 6MM 7556603 | Collar, 7-in OD, Not Shown. | All |
| | 8PP 7560001 | Adjustable Key, Not Shown | All |

This Page Intentionally Left Blank




Parts Drawing 2, Power Pack Assembly for 6" O.D. Arms (10', 14')

| Item | Part Number | Description | Model |
|------|-------------|--|-------|
| 15 | 8PP 0509700 | 1/4-in Diameter Rope-Type Sealant | All |
| 16 | 6MM 3237800 | Collar Ring Mount Adapter | All |
| 17 | 2SG 7537331 | Power Pack, 2 Hp, 60 Hz, Steel Wheel and Housing, motor not included | All |
| 17 | 2SG 7537332 | Power Pack, 2 Hp, 60 Hz, Aluminum Wheel, Steel Housing, motor not included | All |
| 17 | 2SG 7537333 | Power Pack, 2 Hp, 50 Hz, Steel Wheel and Housing, motor not included | All |
| 17 | 2SG 7537334 | Power Pack, 2 Hp, 50 Hz, Aluminum Wheel, Steel Housing, motor not included | All |
| 18 | 8PP 0167700 | Motor, 2 Hp, TEFC, 3450, 208-230/460/60/3, 2HPVT, 145TC Frame, 7/8 Shaft | All |
| 18 | 8PP 0168000 | Motor, 2 Hp, TEFC, 3450, 575/60/3, 2HPVT, 145TC Frame, 7/8 Shaft | All |
| 18 | 8PP 2070200 | Motor, 2 Hp, TEFC, 3450, 115/208-230/60/1, 2HPVT, 145TC Frame, 7/8 Shaft | All |
| 18 | 8PP 2407900 | Motor, 2 Hp, TEFC, 2850, 380/50/3, 2HPVT, 145TC Frame, 7/8 Shaft | All |
| 18 | 8PP 0167800 | Motor, 2 Hp, EP, 3450, 230/460/60/3, 2HPVE, 145TC Frame, 7/8 Shaft | All |
| 18 | 8PP 4489800 | Motor, 2 Hp, EP, 2850, 220/380/440/50/3, 2HPVE, 145TC Frame, 7/8 Shaft | All |
| 19 | 6MM 1066400 | Motor Mount Plate | All |
| 20 | 8PP 1034300 | Blower Wheel, Steel, 60 Hz, 7/8-in Bore | All |
| 20 | 8PP 1486000 | Blower Wheel, Aluminum, 60 Hz, 7/8-in Bore | All |
| 21 | 4MA 2762600 | Blower Housing | All |



Parts Drawing 3, Control Box for 6" O.D. Arms (10', 14')

| Item | Part Number | Description | Model |
|------|-------------|--|-------|
| 25 | 3EA 2764001 | Control Box, 110-Volt, Single Phase | 60 Hz |
| 25 | 3EA 2764002 | Control Box, 220-Volt, Single Phase | 60 Hz |
| 25 | 3EA 2764003 | Control Box, 208-Volt, Three Phase | 60 Hz |
| 25 | 3EA 2764004 | Control Box, 230-Volt, Three Phase | 60 Hz |
| 25 | 3EA 2764005 | Control Box, 460-Volt, Three Phase | 60 Hz |
| 25 | 3EA 2764006 | Control Box, 575-Volt, Three Phase | 60 Hz |
| 25 | 3EA 2764007 | Control Box, 380-Volt, Three Phase | 50 Hz |
| 26 | 8PP 2757300 | Transformer, 120 to 12-Volt, 50/60 Hz | All |
| 27 | 8PP 2728600 | Transformer, 208 to 120-Volt, 50/60 Hz | All |
| 27 | 8PP 2444400 | Transformer, 230/460 to 120-Volt, 50/60 Hz | All |
| 27 | 8PP 2713000 | Transformer, 575 to 120-Volt, 50/60 Hz | All |
| 27 | 8PP 4053800 | Transformer, 380 to 110-Volt, 50 Hz | 50 Hz |
| 28 | 8PP 2757200 | Starter Contactor | All |
| 29 | 8PP 2764201 | Motor Overload Heater, 110-Volt, Single Phase | All |
| 29 | 8PP 2764202 | Motor Overload Heater, 220-Volt, Single Phase | All |
| 29 | 8PP 2764203 | Motor Overload Heater, 208/380-Volt, Three Phase | All |
| 29 | 8PP 2764204 | Motor Overload Heater, 460-Volt, Three Phase | All |
| 29 | 8PP 2764205 | Motor Overload Heater, 575-Volt, Three Phase | All |
| 30 | 8PP 2757400 | Relay Socket, 300-V, 10A | All |
| 31 | 8PP 2673903 | Fusetron® Dual Element 10 Amp Fuse, FNM 10 | All |
| 32 | 8PP 2122400 | MDX-3, 3 Amp Slo-Blow Fuse, 125-Volt AC | All |
| 33 | 8PP 1850500 | Enclosure, NEMA 4 | All |
| 34 | 8PP 4264400 | Fuse Block Assembly | All |
| 35 | 8PP 2757000 | Relay, 12-Volt AC, 10 Amp, SPDT | All |



Parts Drawing 4, Extension Boom

| Item | Part Number | Description | Model |
|---|-------------|----------------------------|-------|
| Extension Boom, 6-in; 10 and 14-ft | | | |
| 1 | 8PP 7557701 | Support Pin | All |
| 2 | 8PP 7557702 | Wall Support Bracket | All |
| 3 | 8PP 7557703 | Bottom Adapter | All |
| 4 | 8PP 7557704 | Tension Bar Bracket | All |
| 5 | 8PP 7557705 | Flex Hose, 6-in OD x 27-in | All |
| 6 | 8PP 7557706 | Flex Hose, 6-in OD x 39-in | All |
| Extension Boom, 7-in; 10 and 14-ft | | | |
| 1 | 8PP 7557701 | Support Pin | All |
| 2 | 8PP 7557702 | Wall Support Bracket | All |
| 3 | 8PP 7557707 | Bottom Adapter | All |
| 4 | 8PP 7557704 | Tension Bar Bracket | All |
| 5 | 8PP 7557708 | Flex Hose, 7-in OD x 27-in | All |
| 6 | 8PP 7557709 | Flex Hose, 7-in OD x 39-in | All |

This Page Intentionally Left Blank

Limited Warranty

Donaldson® warrants to the original purchaser that the major structural components of the goods will be free from defects in materials and workmanship for ten (10) years from the date of shipment, if properly installed, maintained and operated under normal conditions. Donaldson warrants all other Donaldson built components and accessories including Donaldson Airlocks, TBI Fans, TRB Fans, Fume Collector products and Donaldson built Afterfilter housings for twelve (12) months from date of shipment. Donaldson warrants Donaldson built filter elements to be free from defects in materials and workmanship for eighteen (18) months from date of shipment. Donaldson does not warrant against damages due to corrosion, abrasion, normal wear and tear, product modification, or product misapplication. Donaldson also makes no warranty whatsoever as to any goods manufactured or supplied by others including electric motors, fans and control components. After Donaldson has been given adequate opportunity to remedy any defects in material or workmanship, Donaldson retains the sole option to accept return of the goods, with freight paid by the purchaser, and to refund the purchase price for the goods after confirming the goods are returned undamaged and in usable condition. Such a refund will be in the full extent of Donaldson's liability. Donaldson shall not be liable for any other costs, expenses or damages whether direct, indirect, special, incidental, consequential or otherwise. The terms of this warranty may be modified only by a special warranty document signed by a Director, General Manager or Vice President of Donaldson. Failure to use genuine Donaldson replacement parts may void this warranty. **THERE EXIST NO OTHER REPRESENTATIONS, WARRANTIES OR GUARANTEES EXCEPT AS STATED IN THIS PARAGRAPH AND ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHETHER EXPRESS OR IMPLIED ARE HEREBY EXPRESSLY EXCLUDED AND DISCLAIMED.**

Parts and Service

For genuine Donaldson Torit replacement filters and parts, call the Parts Express Line

800-365-1331 USA

800-343-3639 within Mexico

www.donaldsontorit.com

For faster service, have unit's model and serial number, parts number, description, and quantity available.



Donaldson®
Filtration Solutions

Donaldson Company, Inc.
Industrial Air Filtration
P.O. Box 1299
Minneapolis, MN 55440-1299
dustmktg@mail.donaldson.com

Donaldson Company, Inc. is the leading designer and manufacturer of dust, mist, and fume collection equipment used to control industrial air pollutants. Our equipment is designed to help reduce occupational hazard, lengthen machine life, reduce in-plant maintenance requirements, and improve product quality.